

OKI

B4200(PN263) Monochrome LED Page Printer Maintenance Manual

ODA / OEL / AOS

2002-11-26 Rev.1

Document Revision History

Rev.No.	Date	Corrected items			Person in charge
		No.	Page	Description of change	
1	2002-11-26			ISSUE	NP4 Ono

PREFACE

This Maintenance Manual describes the field maintenance methods for B4200 Monochrome LED Page Printers.

This manual is written for use by service persons. Please note that you should refer to the Printer Handbook for the handling and operating methods of the equipment.

CONTENTS

1. CONFIGURATION	7
1.1 System Configuration	7
1.2 Printer Configuration	8
1.3 Optional Configuration	9
1.4 Specification	11
1.5 Safety Standards	13
1.5.1 Certification Label	13
1.5.2 Warning Label	13
1.5.3 Warning/Caution Marking	14
2. PARTS REPLACEMENT	15
2.1 Precautions for Parts Replacement	15
2.2 Parts Layout.....	17
2.3 How to Change Parts.....	20
2.3.1 Upper Cover Assy	21
2.3.2 LED Head	22
2.3.3 Operator Panel Assy	23
2.3.4 Lower Base Unit	24
2.3.5 Pulse Motor (Main/Drum)	25
2.3.6 Pulse Motor (Registration)	26
2.3.7 Face Up Stacker Assy	27
2.3.8 Eject Roller Assy	28
2.3.9 Motor Assy	29
2.3.10 Hopping Roller Shaft Assy.....	30
2.3.11 Stacker Cover Assy	31
2.3.12 Registration Roller	32
2.3.13 Roller Transfer Assy	33
2.3.14 Fusing Unit	34
2.3.15 Back-up Roller	35
2.3.16 Sensor Plate (Inlet)	36
2.3.17 Sensor Plate (Outlet), Sensor Wire Assy	37
2.3.18 Manual Feed Guide Assy	38
2.3.19 Sensor Plate (Paper Supply)	39
2.3.20 GRG-PCB	40
2.3.21 Power Supply Board and High Voltage/Sensor Unit	41
2.3.22 Cassette Guide L Assy	42
2.3.23 Cassette Guide R Assy	43
3. ADJUSTMENT	44
3.1 Adjustment Types and Functions	44
3.1.1 Status Monitor	44
3.1.2 Engine Maintenance Utility	44
3.2 Adjustment When Replacing a Part	45
3.2.1 Uploading/Downloading EEPROM data	45
4. PERIODICAL MAINTENANCE	46
4.1 Periodical Replacement Parts	46
4.2 Cleaning	46
4.2.1 Cleaning of LED Lens Array	46
4.2.2 Cleaning Page Function	47

5. TROUBLESHOOTING PROCEDURES	48
5.1 Troubleshooting Tips	48
5.2 Check Points Before Correcting Image Problems	48
5.3 Notes When Correcting Image Problems	48
5.4 Preparation Before Troubleshooting	49
5.5 Troubleshooting	52
5.5.1 Status Monitor Message List	52
5.5.2 Status Message Troubleshooting	56
5.5.3 Image Troubleshooting	64
6. WIRING DIAGRAM	73
6.1 Interconnect Signal Diagram	73
6.2 PCB Layout and Connector Signal List	74
6.3 Resistance Check	84
7. PARTS LIST	86
APPENDIX A RS-232C SERIAL INTERFACE (OPTION)	91
APPENDIX B CENTRONICS PARALLEL INTERFACE	93
APPENDIX C UNIVERSAL SERIAL BUS (USB)	97
APPENDIX D MULTI PURPOSE FEEDER MAINTENANCE	101
1. OUTLINE	101
1.1 Functions	101
1.2 External View and Component Names	101
2. MECHANISM DESCRIPTION	102
2.1 General Mechanism	102
2.2 Hopper Mechanism	102
3. PARTS REPLACEMENT	103
3.1 Precautions Concerning Parts Replacement	103
3.2 Parts Layout	104
3.3 Parts Replacement Methods	105
3.3.1 Link	106
3.3.2 Separator	107
3.3.3 OLEV-11-PCB	108
3.3.4 Pulse Motor	109
3.3.5 Planet Gear	110
3.3.6 Roller-A and B	111
4. TROUBLESHOOTING	112
4.1 Precautions Prior to the Troubleshooting	112
4.2 Preparations for the Troubleshooting	112
4.3 Troubleshooting Method	113
4.3.1 LCD Status Message List	113
5. CONNECTION DIAGRAM	115
5.1 Interconnection Diagram	115
5.2 PCB Layout	115
6. PARTS LIST	116
APPENDIX E HIGH CAPACITY SECOND PAPER FEEDER	118
1. OUTLINE	118
1.1 Functions	118
1.2 External View and Component Names	118

2.	MECHANISM DESCRIPTION	119
2.1	General Mechanism	119
2.2	Hopper Mechanism	119
3.	PARTS REPLACEMENT	120
3.1	Precautions Concerning Parts Replacement	120
3.2	Parts Layout	121
3.3	Parts Replacement Methods	122
3.3.1	Stepping Motor (Hopping)	123
3.3.2	TQSB-2 PCB	125
3.3.3	Hopping Roller Shaft Assy and One-way Clutch Gear	125
4.	TROUBLESHOOTING	126
4.1	Precautions Prior to the Troubleshooting	126
4.2	Preparations for the Troubleshooting	126
4.3	Troubleshooting Method	127
4.3.1	LED Status Message List	127
5.	CONNECTION DIAGRAM	129
5.1	Interconnection Diagram	129
5.2	PCB Layout	129
6.	PARTS LIST	130

1. CONFIGURATION

1.1 System Configuration

B4200 consists of control and engine blocks in the standard configuration, as shown in Figure 1-1.

In addition, the options marked with asterisk(*) are available.




Figure 1-1

1.2 Printer Configuration

The printer unit consists of the following hardware components:

- Electrophotographic Processor
- Paper Feeder
- Controller
- Operator Panel
- Power Supply Unit

The printer unit configuration is shown in Figure 1-2.





Figure 1-2


1.3 Optional Configuration

The options shown below are available for use with B4200. These are available separately from the printer unit.


(1) High Capacity Second Paper Feeder




(2) Multi Purpose Feeder




(3) RS232C Serial Interface Board



(4) SDRAM DIMM




(i) 16MB




(ii) 32MB

(5) Flash DIMM



(i) 8MB



(ii) 16MB

1.4 Specification

(1) Type	Desktop
(2) External dimensions	Height 7.9" (200 mm) Width 14.0" (355 mm) Depth 15.7" (400 mm)
(3) Weight	Approx. 9 kg
(4) Developing method Exposing method	Dry electrophotography LED stationary head
(5) Paper used	<p><Type></p> <ul style="list-style-type: none"> Standard paper <ul style="list-style-type: none"> Xerox 4200 (20 lbs) Application paper (manual face-up feed) <ul style="list-style-type: none"> Label Envelope OHP paper (transparency) <p><Size></p> <ul style="list-style-type: none"> Standard sizes <ul style="list-style-type: none"> Letter Legal* [* Without Multi Purpose Feeder (Option)] Legal-13* Executive COM-9 ** COM-10** [** manual feed and Multi Purpose Feeder (option) only] Monarch** DL ** C5** A4 A5 B5 (JIS) A6 Applicable sizes <ul style="list-style-type: none"> Width : 3.5" to 8.5" (90 to 216 mm) Length : 5.8" to 14" (148 to 355.6 mm) <p><Thickness></p> <ul style="list-style-type: none"> Automatic feed : 16 to 28 lbs (60 to 105 g/m²) Manual feed : Label, OHP paper (transparency) Envelope (24 to 28 lbs)
(6) Printing speed	<p>Continuous printing : 19 pages per minute with Letter size paper. 18 pages per minute with A4 size paper. [Except, Multi purpose Feeder (11ppm)]</p> <p>Warm-up time : 35 seconds typical at room temperature [68°F (20°C), AC 120/230 V].</p> <p>First page print time : 6.0 seconds typical for the Letter size paper (6.2 seconds for the A4 size) after warm-up.</p>
(7) Paper feeding method	Automatic feed or manual feed
(8) Paper delivery method	Face down/face up
(9) Resolution	600 × 600 dots/inch 600 × 1200 dots/inch


(10) Power input 120 VAC + 6%, -10%
 230 VAC \pm 10%

(11) Power consumption		120VAC	230VAC
Peak	:	Approx. 700W	Approx. 700W
Typical operation	:	Approx. 340W	Approx. 350W
Idle	:	Approx. 66W	Approx. 68W
Power save mode	:	Approx. 8W	Approx. 9W
(Without option)			
Power save mode	:	Approx. 12W	Approx. 13W
(With full option)			

(12) Temperature and humidity

	In operation	Power off mode	During Storage	Unit
Temperature	50-90 (10-32)	32-110 (0-43)	14-110 (-10-43)	°F (°C)
Humidity	20-80	10-90	10-90	%RH
Maximum wet bulb temperature	77 (25)	80.4 (26.8)	—	°F (°C)
Minimum difference between wet and dry bulb temperatures	35.6 (2)	35.6 (2)	—	°F (°C)

1. Storage conditions specified above apply to printers in packed condition.
2. Temperature and humidity must be in the range where no condensation occurs.




(13) Noise	During operation	: 53 dB (A) or less
	Standby	: 38 dB (A) or less
	Quiet mode	: Back ground level

(14) Consumables	Toner cartridge kit	2,500 (5% duty) 6,000 (Optional 6K Toner 5% duty)
	Image drum cartridge	25,000 (at continuouts printing) 17,000 (3 page/job) without Power Save 11,000 (1 page/job) without Power Save 7,000 (1 page/job) with Power Save (Minimum)

1.5 Safety Standards

1.5.1 Certification Label


The safety certification label is affixed to the printer in the position described below.



1.5.2 Warning Label


The warning labels are affixed to the sections which may cause bodily injury.

Follow the instructions on warning labels during maintenance.



1.5.3 Warning/Caution Marking

The following warning and caution markings are made on the power supply/sensor board.



ENGLISH

Heatsink and transformer core present risk of electric shock. Test before touching.

FRENCH

Le dissipateur thermique et le noyau du transformateur présentent des risques de choc électrique. Testez avant de manipuler.

SPANISH

Las disipadores de calor y el núcleo del transformador pueden producir un choque eléctrico. Compruebe antes de tocar.

PORTUGUESE

O dissipador de calor e o núcleo do transformador apresentam risco de choque elétrico. Teste antes de tocar.

ENGLISH

Circuits maybe live after fuses open.

FRENCH

Il se peut que les circuits soient sous tension une fois que les fusibles ont été retirés.

SPANISH

Las circuitos pueden estar activos una vez que se hayan abierto los fusibles.

PORTUGUESE

Os circuitos podem estar energizados após os fusíveis se queimarem.

2. PARTS REPLACEMENT

The section explains the procedures for replacement of parts, assemblies, and units in the field. Only the disassembly procedures are explained here. For reassembly, reverse the disassembly procedure.

2.1 Precautions for Parts Replacement


(1) Before starting to replace parts, remove the AC cord and interface cable.

(a) Remove the AC cord in the following sequence:

- i) Turn off ("o") the power switch of the printer
- ii) Disconnect the AC inlet plug of the AC cord from the AC receptacle.
- iii) Disconnect the AC cord and interface cable from the printer.

(b) Reconnect the printer in the following procedure.

- i) Connect the AC cord and interface cable to the printer.
- ii) Connect the AC inlet plug to the AC receptacle.
- iii) Turn on ("I") the power switch of the printer.











- (2) Do not disassemble the printer as long as it is operating normally.
- (3) Do not remove parts which do not have to be touched; try to keep the disassembly to a minimum.
- (4) Use specified service tools.
- (5) When disassembling, follow the laid out sequences. Parts may be damaged if these sequences are not followed.
- (6) Since screws, collars and other small parts are likely to be lost, they should temporarily be attached to the original positions during disassembly.
- (7) When handling IC's such as microprocessors, ROMs and RAMs, or circuit boards, do not wear gloves that are likely to generate static electricity.
- (8) Do not place printed circuit boards directly on the equipment or floor.

[Service Tools]

The tools required for field replacement of printed circuit boards, assemblies and units are listed in Table 2-1.

Table 2-1 Service Tools

No.	Service Tools	Q' ty	Application	Remarks
1	 No. 1-100 Philips screwdriver	1	2~2.5 mm screws	
2	 No. 2-100 Philips screwdriver	1	3~5 mm screws	
3	 No. 3-100 screwdriver	1		
4	 No. 5-200 screwdriver	1		
5	 Digital multimeter	1		
6	 Pliers	1		
7	 Handy cleaner	1		
8	 LED Head cleaner	1	Cleans LED head	

2.2 Parts Layout

This section explains the layout of main components of the equipment.

[Lower base unit]




Figure 2-1

[Upper cover unit]




Figure 2-2

[Base unit]





Figure 2-3

2.3 How to Change Parts

This section explains how to change parts and assemblies listed in the disassembly diagram below.


In the parts replacement procedure, those parts marked with the part number inside ● with white letters are RSPL parts.



2.3.1 Upper Cover Assy

- (1) With the power switch turned off, unplug the AC power cord from the outlet.
- (2) Disconnect the interface cable ①.
- (3) Press the button ② on right side of the Upper cover and open the stacker cover assy ③.
- (4) Take out the image drum unit ④.
- (5) Remove one screw ⑤, and remove the I/F cover ⑥ from the back side of the printer.
- (6) Open the manual feed guide assy ⑦. Unlock the latches at two locations on the front side. Lift the front side of the upper cover ⑧ up and unlock the latches at two locations on the back side. Lift and remove the upper cover assy ⑧.


Note : When removing or reinstalling the upper cover, be careful not to get the motor cables tangled or caught.



2.3.2 LED Head

- (1) Press the button on right side of the upper cover and open the stacker cover assy ❶.
- (2) Open the hook section on the left side of the head holder and remove the LED head ❷.
- (3) Remove the head cable ❸ from the head connector.


Note: Be sure not to touch directly or push on the SLA part of the LED head.



2.3.3 Operator Panel Assy


- (1) Unlock two latches on the upper cover from the rear side, lift the operator panel assy ❶ from the back and remove it.
- (2) Remove the Sumi card (operator panel) ❷ from the connector (CN1) ❸.

Note : You can remove the operator panel assy while the upper cover installed on the unit. However, it is much easier to remove the panel assy after removal of upper cover.




2.3.4 Lower Base Unit

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the transfer roller assy (see 2.3.13).
- (5) Remove the connecting cables ① and ② of the pulse motors from the connectors (DM, RM) of the GRG-PCB ③.
- (6) Remove the LED head cables ④ from the connector (HEAD1).
- (7) Remove the Thermistor cable ⑤ from the connector (THERM).
- (8) Remove the connecting cable ⑥ of the heater from the connector (CN2).
- (9) Open the manual feed guide assy, remove seven screws ⑦, then remove the lower base unit ⑧.




2.3.5 Pulse Motor (Main/Drum)

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the lower base unit (see 2.3.4).
- (3) Remove two screws ① and remove the pulse motor (main/drum) ② from the motor bracket ③.




View A




2.3.6 Pulse Motor (Registration)

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the lower base unit (see 2.3.4).
- (3) Remove two screws ① and remove the pluse motor (registration) ② from the motor bracket ③.




View A




2.3.7 Face Up Stacker Assy

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the Sumi card (Operator panel cable) ❶ off the latch section of face up stacker ❷ .
- (4) Remove three screws ❸ and remove both the shield plate ❹ and face up stacker ❷ together.
- (5) Unlock the latches at two locations, and remove the face up stacker ❷.




2.3.8 Eject Roller Assy

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the stacker cover assy (see 2.3.11).
- (5) Disengage the eject roller assy ❶ from the lower base ❷ by pressing the latch section of the eject roller assy ❶ in the direction of the arrow shown below, and remove the eject roller assy ❶.




2.3.9 Motor Assy

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Stand the lower base unit on its side as shown, and unlock two latches, then remove the motor assy ①.
- (6) Remove two screws ② and remove the bracket-Motor-Sub ③ from the Motor bracket.



2.3.10 Hopping Roller Shaft Assy


- (1) Remove the upper cover (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Remove the motor assy (see 2.3.9).
- (6) With the lower base unit ❶ standing on its side, remove the one-way clutch gear ❷ and the bearing (A) ❸.
- (7) Remove the hopping roller shaft assy ❹ (the bearing (B) ❺ comes off, so be careful not to lose it).



2.3.11 Stacker Cover Assy


- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the motor assy (see 2.3.9).
- (5) Remove the reset lever R ❶.
- (6) Remove one screw, detach the reset spring ❷ from the lower base unit ❸, turn the reset lever L ❹ in the direction of arrow ❸ until it stops, and remove it in the direction of arrow ❹.
- (7) Unlock two latches of the lower base unit ❸, then remove the stacker cover assy ❺.

Note : When reinstalling the reset lever L ❹, fit it onto the guide of the lower base unit ❸, turn it in the direction of arrow ❸ while pressing down the shaft of back up roller, and engage the reset lever L ❹.




2.3.12 Registration Roller

- (1) Remove the upper cover (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Remove the motor assy (see 2.3.9).
- (6) Unlock the latch at the left side of the paper guide (R) ❶ and remove the paper guide (R) ❶.
- (7) With the lower base unit standing on its side, remove the one-way clutch gear ❷ and the bearing ❸.
- (8) Remove the Registration Gear by unlocking the latch of the Gear ❹.
- (9) Remove the Registration Bearing L ❺.
- (10) Press the registration roller ❻ in the direction of arrow ➀ and lift up the left side of it, then remove the registration roller Assy ❼.
- (11) Pull out the registration roller Assy ❼ in the direction of arrow ➁.
- (12) Remove the pressure roller Assy gear ❸ by unlocking the latch of the gear ❸.
- (13) Remove the bearing-Registration L ❹ and bearing Registration R ❺.
- (14) Remove the Spring ❾ from the bearing ❹, ❺.



2.3.13 Roller Transfer Assy

- (1) With the power switch turned off, unplug the AC cord from the outlet.
- (2) Open the stacker cover.
- (4) Remove the spacer ①.
- (4) Release the roller transfer assy ② by unlocking two latches of the bearing TR (never apply excessive force when unlocking the latch) and slide the roller transfer assy left to remove the gear from the bracket.
- (5) Lift the right side of the roller transfer assy ②, and shift it to the right side, then pull it out from the main unit (at this time, the bearings ③ of the left side and holder-TR ④ of the right side of the roller transfer assy ② will also come off).




2.3.14 Fusing Unit

- (1) Remove the upper cover (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Remove the stacker cover assy (see 2.3.11).
- (6) Remove the connecting cable ① of the heater and connecting cable ② of the thermistor from the hooks of the lower base.
- (7) Remove four screws ③, lift and remove the fusing unit ④.


Caution: Fusing unit may be hot. Use care when handling.

- Notes :**
1. When reinstalling or removing the fusing unit, tighten or loosen the screws while holding the fusing unit assy ④ down with your hand (it is being pushed up by back up roller).
 2. When reinstalling the screws ③, be sure to direct the screws into preexisting thread and avoid damaging the threads.
 3. Do not apply excessive torque when tightening the screws ③.




2.3.15 Back-up Roller

- (1) Remove the fusing unit assy (see 2.3.14).
- (2) Lift the left side of the back-up roller ❶, and pull it out to the left side (at this time, two bearing Holders (back-up) ❷ and the bias springs (back-up) ❸ and the two ball-bearings ❹, washer C ❺ will also come off).




2.3.16 Sensor Plate (Inlet)

- (1) Remove the upper cover (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Unlock the latch at the left side of the paper guide (R) ❶ and remove the paper guide (R) ❶.
- (6) Press the clamps of three sensor plates (inlet and paper) ❷, and remove them by pressing them upward from the bottom.



2.3.17 Sensor Plate (Outlet), Sensor Wire Assy



- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the eject roller assy (see 2.3.8).
- (4) Remove the face up stacker assy (see 2.3.7).
- (5) Remove the lower base unit (see 2.3.4).
- (6) Remove the fusing unit assy (see 2.3.14).
- (7) Press the clamps of the sensor plate (outlet) ❶, and remove the sensor plate by pushing it up.
- (8) Turn the clamps of the sensor wire assy ❷ remove the sensor wire assy from the lower base unit.



2.3.18 Manual Feed Guide Assy


- (1) Remove the upper cover assy (see 2.3.1).
- (2) Open the manual feed guide assy ❶, and release the engagement on both sides with the main unit by carefully bending the manual feed guide assy ❶.

Note : When remounting, verify the proper the engagements as shown in the diagram.



2.3.19 Sensor Plate (Paper Supply)


- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Press the clamps of the sensor plate (paper supply) ❶ to unlock the latch, and remove it from the base plate ❷.



2.3.20 GRG-PCB

- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the operator panel assy (see 2.3.3).
- (3) Remove the face up stacker assy (see 2.3.7).
- (4) Remove the lower base unit (see 2.3.4).
- (5) Remove three screws ① and two screws ②.
- (6) Remove the connector FAN, and disconnect the fan motor ③.
- (7) Remove the three connectors PWZ, PS1 and HVIF.
- (8) Remove the GRG-PCB ④ and plate earth (A) ⑤.


Note : When reinstalling the GRG-PCB ④ onto the base plate ⑥, insert the edge of the GRG-PCB ④ in two slots of the base plate ⑥.



2.3.21 Power Supply Board and High Voltage/Sensor Unit


- (1) Remove the upper cover assy (see 2.3.1).
- (2) Remove the lower base unit (see 2.3.4).
- (3) Remove two screws ① and the guide plate ②.
- (4) Remove the AC inlet ③ from the guide plate ②.
- (5) Remove the screw ④ and remove the grounding (earth) wire ⑤.
- (6) Remove the connectors CN2 from power supply board ⑥ and CN1 from high voltage/sensor unit ⑦.
- (7) Remove ten screws ⑧, and remove the power supply board ⑥ and high voltage/sensor unit ⑦.
- (8) Remove the Insulation plate ⑨ from the base plate ⑩.

- Notes :**
1. Be careful about the sensor (paper supply) when reinstalling the lower base.
 2. Make sure that no excessive force is applied to the power supply switch.
 3. When installing the power supply/sensor onto the base plate, be careful not to bend the base plate (it is desirable to place a block underneath it to prevent bending).




2.3.22 Cassette Guide L Assy

- (1) Remove the paper cassette.
- (2) Remove the upper cover assy (see 2.3.1).
- (3) Remove the lower base unit (see 2.3.4).
- (4) Remove two screws ①, and remove the beam plates ②.
- (5) Remove the cassette guide L Assy ③ by shifting it in the direction of the arrow as shown below.
- (6) Remove the earth plate ④.



2.3.23 Cassette Guide R Assy

- (1) Remove the paper cassette.
- (2) Remove the upper cover assy (see 2.3.1).
- (3) Remove the lower base unit (see 2.3.4).
- (4) Remove two screws ①, and remove the beam plates ②.
- (5) Remove the cassette guide R Assy ③ by shifting it in the direction of arrow.
- (6) Remove the earth plate ④ and the cassette lock spring ⑤.



3. ADJUSTMENT

This chapter explains adjustment necessary when a part is replaced.

This adjustment is made by changing the parameter values set in EEPROM on the main control board. The status monitor or maintenance utility can be used to change these values.

Only servicemen and maintenance personnel can use the maintenance utility. This utility cannot be made public for printer end users.

3.1 Adjustment Types and Functions

3.1.1 Status Monitor

(TBD)

3.1.2 Engine Maintenance Utility

(TBD)

3.2 Adjustment When Replacing a Part

Adjustment is necessary when replacing any of the following parts.

Part Replaced	Adjustment
Image Drum Cartridge	Reset the image drum counter (refer to User's manual).
Main Control Board	EEPROM data Upload / Download

3.2.1 Uploading/Downloading EEPROM data

When the controller printed circuit board is replaced, the contents of the old EEPROM shall be copied to the new EEPROM on the new board to preserve customer settings. For the purpose, use the EEPROM operation on the Option of the Maintenance Utility. To copy follow the steps below.

- (1) Be sure to confirm that the printer and the PC are connected with a centronics I/F cable. Then execute the Maintenance Utility.
Note: Printer driver shall be deinstalled.
- (2) Select the Option on the Maintenance Utility.
- (3) Click the "UPLOAD EEPROM" button on the "EEPROM Operations".
- (4) The contents of the EEPROM data is displayed on the "DIALOG" of the Maintenance Utility. The contents of the old EEPROM is now copied into the memory of the PC.
- (5) Replace the controller P.C.B. with a new one while it displays the above "DIALOG".
- (6) After the replacement, click "Downloaded EEPROM" on the "EEPROM Operations". EEPROM upload has been completed.

In case of troubles such as centronics I/F failure, etc. EEPROM data may not be uploaded properly. In such case, it is necessary to adjust the following settings manually after the replacement using the Maintenance Utility.

- Factory setting (ODA/OEL/AOS)

The maintenance utility is designed to be used only by field engineer and it should not be released to the end-users.

4. PERIODICAL MAINTENANCE

4.1 Periodical Replacement Parts

The parts are to be replaced periodically as specified below:

Part name	Condition for replacement	Cleaning	Remarks
• Toner cartridge 2.5K (Type 9)	About 2,500 sheets of paper have been printed.	• LED head	Consumables
• Image drum cartridge (Type 9)	About 25,000 sheets of paper have been printed. See 1.4. (14)		Consumables

4.2 Cleaning

Remove any toner or dust accumulated inside the printer. Clean in and around the printer with a piece of cloth when necessary. Use the handy cleaner (service tool) to clean inside the printer.


Note: Do not touch the image drum, LED lens array, or LED head connector block.

4.2.1 Cleaning of LED Lens Array

Clean the LED lens array or replace the toner cartridge when white lines or stripes (void, light printing) are generated vertically down the page, as shown below.


Note: The LED lens array must be cleaned with an LED head cleaner included in the replacement toner kit.

White lines or stripes
(void, light printing)



- (1) Set the LED head cleaner to the LED lens array as shown in the figure, then slide the cleaner back and forth horizontally several times to clean the head.

Note: Gently press the LED head cleaner onto the LED lens array.



- (2) Throw the cleaner pad away.

4.2.2 Cleaning Page Function

There is a charge roller cleaning function with this printer, which can be executed by the user.

- (1) Press the control switch to take the printer off line.
- (2) Open the manual feed tray and insert a sheet of A4 plain paper between the paper guides.
- (3) Press and hold down the control switch for at least five seconds.
- (4) The printer grips the paper and prints a cleaning page.
- (5) Return the printer on line by pressing the control switch.
- (6) If subsequent printing appears faded or uneven, try replacing the toner cartridge.

5. TROUBLESHOOTING PROCEDURES

5.1 Troubleshooting Tips

- (1) Check the basic check points written in the user's manual.
- (2) Gather detailed failure information as much as possible from the customer.
- (3) Check the printer under the condition close to that under which the failure occurred.

5.2 Check Points Before Correcting Image Problems

- (1) Is the printer running in proper ambient conditions?
- (2) Are consumables (toner and EP unit) replaced correctly?
- (3) Are sheets of paper normal?
- (4) Is the EP unit set correctly?

5.3 Notes When Correcting Image Problems

- (1) Do not touch the surface of the OPC drum nor place foreign matter on it.
- (2) Do not expose the OPC drum to direct sunlight.
- (3) Do not touch the fuser because it heats up during operation.
- (4) Do not expose the image drum to light for more than five minutes at room temperature.

5.4 Preparation Before Troubleshooting

(1) Message display

The failure status of printer is displayed on the status monitor of the PC.

Take proper action according to the message displayed on the status monitor.

(2) LED indicator

Printer is equipped with three LED. These LED indicates one of the following status:

For ODA





For OEL/INT






- ① Ready LED Indicator
- ② Manual Feed LED Indicator
- ③ Error LED Indicator

LED Functions(1/2)

Status	 Ready (green)	 Manual Feed (amber)	 Error (amber)	Remark
Online(Ready)	ON	OFF	Undefined	
Offline	OFF	OFF	Undefined	
Data Arrive	Flash 2	OFF	Undefined	
Data Processing	Flash 2	OFF	Undefined	
Data Exist	Flash 1	OFF	Undefined	
Printing	Flash 2	OFF	Undefined	
Printing (copy)	Undefined	OFF	Undefined	
Canceling Job	Flash 1	OFF	Undefined	
Canceling Job	Flash 1	OFF	Undefined	
Warming Up	Flash 1	OFF	OFF	
Power Saving	Undefined	OFF	OFF	
Toner Low	Undefined	Undefined	Flash 1 or Flash 2	
Toner Empty	Undefined	OFF	Flash 2	
Toner Sensor Error	Undefined	Undefined	Flash 1	
Change Drum	Undefined	Undefined	Flash 3	
Print Demo	Flash 2	Undefined	Undefined	
Print Fonts	Flash 2	Undefined	Undefined	
Print Menu Map	Flash 2	Undefined	Undefined	
Print Cleaning	Flash 2	Undefined	Undefined	
Invalid data	Undefined	OFF	Flash 2	
tttt tray paper out (BACK GROUND)	Undefined	Undefined	Flash 1	
Tray2 cover open	Undefined	Undefined	Flash 1	
File System Error (File System full)	Undefined	Undefined	Flash 1	
File System Error (Write Protect)	Undefined	Undefined	Flash 1	
File System Error (Operation failure)	Undefined	Undefined	Flash 1	
Manual Paper Request	Undefined	Flash 2	Undefined	
tttt Tray mmmm Paper Request	OFF	OFF	Flash 2	
Tray2 cover open	OFF	OFF	Flash 2	
tttt Tray mmmm Paper Media Mismatch	OFF	OFF	Flash 2	
tttt Tray mmmm Paper Size Mismatch	OFF	OFF	Flash 2	
RS232C Overflow Error	OFF	OFF	Flash 2	
RS232C Overrun Error	OFF	OFF	Flash 2	
RS232C Parity Error	OFF	OFF	Flash 2	
RS232C Framing Error	OFF	OFF	Flash 2	
Toner Empty	OFF	OFF	Flash 2	
Page Buffer Overflow	OFF	OFF	Flash 2	
Paper Size Error	OFF	OFF	Flash 2	

Flash 1: Slow blinking
Flash 2: Blinking
Flash 3: Fast blinking

LED Functions(2/2)

Status	 Ready (green)	 Manual Feed (amber)	 Error (amber)	Remark
Paper Induct Jam	OFF	OFF	Flash 2	
Paper Feed Jam	OFF	OFF	Flash 2	
Paper Exit Jam	OFF	OFF	Flash 2	
Change Drum	OFF	OFF	Flash 2	
I/D Not Installed	OFF	Undefined	Flash 2	
Cover Open	OFF	Undefined	Flash 2	
Restarting Printer	OFF	OFF	Flash 2	
Fatal Error	Flash 3	Flash 3	Flash 3	
During initializing	OFF	OFF	OFF	
Initializing EEPROM	OFF	OFF	OFF	
Checking RAM	OFF	OFF	OFF	
During initializing EEPROM	Flash 2 (3 times)	Flash 2 (3 times)	Flash 2 (3 times)	
Drum counter being reset	Flash 2 (2 times)	Flash 2 (2 times)	Flash 2 (2 times)	
Forced ROM start-up function Rising	Flash 2	Flash 2	Flash 2	
During initializing	ON and then OFF	ON and then OFF	ON and then OFF	


Flash 1: Slow blinking

Flash 2: Blinking

Flash 3: Fast blinking

5.5 Troubleshooting

If a trouble occurs in the printer, troubleshoot according to the following procedures:



5.5.1 Status Monitor Message List

Table 5-1 lists the statuses and troubles to be displayed on the status monitor in the message format.

Table 5-1

Category	Status Message	Code	Display Content	Remedy
Normal status	Warming Up	10003	Warming-up status	Normal operation
	Online (Ready)	10001	Online (ready) status	Normal operation
	Power Save Mode	10094	Power save status	Normal operation
	Toner Low	10006	The toner amount of the toner cartridge is small.	Normal operation
	Toner Sensor	10093	The toner sensor is faulty.	Replace the toner sensor.
	Change Drum	40093	Life of I/D drum	Change the I/D Unit and reset Drum counter see Section 3.1.1 (1)
	Manual Paper In	10097	The paper is in the manual feed mode.	Normal operation
	Printing In Progress	10098	Printing in progress X=0, Non Warning X=1, Toner Low X=2, 3 Change Drum	Normal operation
	Ejection In Progress	10099	Ejection in progress X=0, Non Warning X=1, Toner Low X=2, 3 Change Drum	Normal operation
	Manual Request Executive Letter Legal 14 Legal 13 A6 A5 A4 B5 Monarch COM-10 DL C5 COM-9	411xx	Request the paper to be set in the manual feed mode. The paper sizes are as follows: Executive, Letter, Legal 14, Legal 13, A4, A5, A6, B5, Monarch, DL, C5, COM-10, COM-9 xx: Paper size in the tray being selected	Set the requested paper in the manual feed mode.

Table 5-1 (Cont'd)

Category	Status Message	Code	Display Content	Remedy
Paper size error	Paper Size Error	30034	Paper of improper size was fed. 2.52" (64 mm) L 15.77" (400.56 mm)	Check the paper. Also check whether more than one sheet of paper were fed simultaneously. To release the error display, open the cover, then close it. If this error occurs frequently, see Section 5.5.2 3.
Paper jam	Paper Input Jam	40077	A paper jam occurred when sheets of paper were being supplied.	Check the paper. To release the error display, close the cover, then close it. If this error occurs frequently, see Section 5.5.2 2-1.
	Paper Feed Jam	40078	A paper jam occurred during paper feeding.	Open the cover, then remove the jammed paper. To release the error display, close the cover. If this error occurs frequently, see Section 5.5.2 2-2.
	Paper Exit Jam	40079	A paper jam occurred during paper ejection.	Open the cover, then remove the jammed paper. To release the error display, close the cover. If this error occurs frequently, see Section 5.5.2 2-3.
Cover open	ID Not Installed	40033		Installed I/D Unit
Buffer overflow	Cover Open	40021	The upper cover is open.	To release the error display, close the cover. If this error occurs frequently, replace the power supply board.
	Page Buffer Overflow	30097	The page buffer overflowed because there are a large number of print data.	To release the error display, press the reset button on the status motor of the printer driver. Install RAM or reduce the number of print data.
Device configuration error	Program ROM Check Error		An error occurred during program ROM check.	Replace program ROM or the main control board. (When replacing the main control board, also adjust EEPROM data.) (See Section 3.2.1)
	Resident RAM Check Error		An error occurred during resident RAM check.	Replace the main control board. (When replacing the main control board, also adjust EEPROM data.) (See Section 3.2.1)
	EEPROM Check Error		An error occurred during EEPROM check.	Replace the main control board. (When replacing the main control board, also adjust EEPROM data.) (See Section 3.2.1)

Table 5-1 (Cont'd)

Category	Status Message	Code	Display Content	Remedy
Device configuration error	Option RAM Check Error		An error occurred during option RAM check.	Check the connection of the Option RAM PC board. If the option RAM PC board is faulty, replace it.
	Fuser Error	40084	A heater timeout error occurred.	See Section 5.5.2 4.
	Thermister Open Check Error		The thermistor is open.	Replace the heater Assy.
	Thermister Short Check Error		A thermistor short occurred.	Replace the heater Assy.
	Watch Dog Timeout Error		A watchdog timeout occurred.	To release the error display, turn on the power supply again. Replace the main control board.
	Motor Timeout Error		A motor timeout occurred.	To release the error display, turn on the power supply again. Replace the main control board.


5.5.2 Status Message Troubleshooting

If the problems cannot be corrected by using the status message/problem list, follow the troubleshooting flowcharts given here to deal with them.

No.	Trouble	Flowchart number
1.	The printer does not work normally after the power is turned on.	①
2.	Jam alarm <ul style="list-style-type: none"> — Paper input jam — Paper feed jam — Paper exit jam 	②-1 ②-2 ②-3
3.	Paper size error	③
4.	Fusing unit error	④
5.	SSIO (Synchronous Serial Input/Output) error I/F timeout (no response) between the printer and an optional tray (High Capacity Second Paper Feeder, Power Envelope Feeder).	⑤
6.	Fan error	⑥

① The printer does not work normally after the power is turned on.


- Turn the power off, then back on.



[JAM error]


②-1 Paper input jam (Paper Jam)

- Does the JAM error occur when the power is turned on?
 - Yes Is the paper at the inlet sensor?
 - Yes Remove the paper.
 - No Is the operation of the inlet sensor plate normal (moves freely when it is touched)?
 - No Replace the inlet sensor plate.
 - Yes Clean the inlet sensor on the power supply/sensor board, or replace the power supply/sensor board.
- No Does the JAM alarm occur after paper feeding?
 - Yes Is the paper fed to the inlet sensor plate?
 - Yes Is the operation of the input sensor plate normal (moves freely when it is touched)?
 - No Replace the inlet sensor plate.
 - Yes Clean the inlet sensor on the power supply/sensor board or replace the power supply/sensor board.
 - No Replace the hopping roller rubber or paper cassette.
- No Is the hopping roller rotating?
 - Yes Set the paper tray properly.
- No Is the registration motor rotating?
 - Yes Replace the one-way clutch gear of the hopping roller assembly.
- No Is RM connector on the main control board being connected properly?
 - No Connect RM connector properly.
- Yes Is the coil resistance (normal resistance: both between Pins 1 and 2, as well as Pins 3 and 4 are about 7.9Ω) of the registration motor normal?
 - No Replace the registration motor.
- Yes Replace the main control board.



[JAM error]

②-2 Paper feed jam



②-2-a

- No Check the gears (transfer roller gear, idle gear and reduction gear).
- ▼ Yes Is the fusing unit being installed properly?
 - No Install the fusing unit properly.
- ▼ Yes Is the image drum cartridge being set properly?
 - No Set the image drum cartridge properly.
- ▼ Yes Clean the paper sensor on the power supply/sensor board or replace the power supply/sensor board.


[JAM error]

②-3 Paper exit jam

- Does the paper exit jam error occur when the power is turned on?
 - Yes Is the paper on the outlet sensor plate?
 - Yes Remove the paper.
 - ▼ No In the operation of the outlet sensor plate normal (moves freely when it is touched)?
 - No Replace the outlet sensor plate.
 - ▼ Yes Clean the outlet sensor on the power supply/sensor board or replace the power supply/sensor board.
- ▼ No Is the face-up stacker pulled out completely from the printer or, pushed into the printer completely?
 - No Pull the face-up stacker out of the printer completely or push it into the printer completely.
- ▼ Yes Is the eject roller assembly being installed properly?
 - No Install the eject roller assembly properly.
- ▼ Yes Has the coil spring come off the eject roller assembly?
 - Yes Install the coil spring to the eject roller assembly.
- ▼ No Replace the eject roller assembly.

③ Paper size error

- Is paper of the specified size being used?
 - No Use paper of the specified size.
- ▼ Yes Are inlet sensor plates 1 and 2 operating properly (moves freely when they are touched)?
 - No Replace the inlet sensor plate or clean the inlet sensor on the power supply/sensor board.
- ▼ Yes Does the outlet sensor plate operate properly (moves freely when it is touched)?
 - No Replace the outlet sensor plate or clean the outlet sensor on the power supply/sensor board.
- ▼ Yes Replace the power supply/sensor board.



- ④ Fusing unit error Status Message :
- : Thermister Open Error
 - : Thermister Short Check Error
 - : Fuser Error Heater temp High
 - : Fuser Error Heater temp Low

• Turn the power off, then back on again.

▼ Yes Is the thermistor open or shorted? Measure the resistance between thermistor contacts (heater contacts 120V/2Ω or 240V/7Ω, and thermistor contacts 200KΩ at room temperature) (see Figure 5-2 or Section 6.3).

• Yes Replace the fusing unit.

▼ No Do the thermistor connector is connected to the main control board connector?

• No Connect the thermistor connector properly.

▼ Yes Is the heater of the fusing unit turned on (when the heater is turned on, light is emitted)?

• Yes Check the thermistor connector or replace the main control board or the fusing unit.

▼ No Is the AC voltage being supplied to the connector for the heater of the power supply board? (see Figure 5-2)

• No Replace the main control board or the power supply/sensor board.

▼ Yes Check the heater connector cord and the heater connector for poor contact .






Figure 5-2

⑤ Synchronous serial I/O error (Status Message : SSIO Error) or I/F timeout between printer and optional tray (Status Message : Tray2 Timeout Error or Feeder Timeout Error)




⑥ Fan error (Status Message : FAN Motor Error)




5.5.3 Image Troubleshooting

Procedures for troubleshooting for abnormal image printouts are explained below. Figure 5-3 below shows typical abnormal images.


Problem	Flowchart number
Images are light or blurred entirely (Figure 5-3 (A))	①
Dark background density (Figure 5-3 (B))	②
Blank paper is output (Figure 5-3 (C))	③
Black vertical belts or stripes (Figure 5-3 (D))	④
Cyclical defect (Figure 5-3 (E))	⑤
Prints voids	⑥
Poor fusing (images are blurred or peels off when the printed characters and images on the paper are touched by hand)	⑦
White vertical belts or streaks (Figure 5-3 (F))	⑧




Ⓐ Light or blurred images entirely




Ⓑ Dark background density




Ⓒ Blank paper



Ⓓ Black vertical belts or stripes



Ⓔ Cyclical defect



Ⓕ White vertical belts or streaks

Figure 5-3

① Images are light or blurred entirely.

• Is toner low (is the TONER LOW message displayed)?

- Yes Supply toner.

▼ No Is paper of the specified grade being used?

- No Use paper of the specified grade.

▼ Yes Is the lens surface of the LED head dirty?

- Yes Clean the lens.

▼ No Is the LED head being installed properly (check the HEAD1 connector of the main control board and PC connector on the LED head for proper connection)?

- No Install the LED head properly.

▼ Yes Is the contact plate of the transfer roller in contact with the contact assembly of the power supply/sensor board properly (see Figure 5-5)?

- No Adjust the contact plate of the transfer roller to make a proper contact with the power supply/sensor board and shaft of the transfer roller.

▼ Yes Are the contact of the developing roller and the contact of the toner supply roller of the image drum cartridge in contact with the contact assembly properly (see Figure 5-4 (A) and (B))?

- No Adjust the contacts of the developing and toner supply roller to make a proper contact with the contact assembly.

▼ Yes Replace the transfer roller.

▼ Has the problem been solved?

- Yes End

▼ No Replace the image drum cartridge.

▼ Has the problem been solved?


- Yes End

Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (See Printer Handbook).


▼ No Is the tension between the back-up roller (7.52kg) and the surface of back-up roller normal?

- No Replace the back-up roller or bias spring.


▼ Yes Replace the main control board or power supply/sensor board.



② Dark background density



③ Blank paper is output.



④ Black vertical belts or stripes

- Perform the cleaning page function (see Section 4.2.2).

▼ Has the problem been solved?

- Yes End.

▼ No Replace the image drum cartridge.

▼ Has the problem been solved?

- Yes End

Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (See Printer Handbook).

▼ Clean the LED lens array of the LED head.

▼ Has the problem been solved?

- Yes End.

▼ No Replace the LED head.

▼ Has the problem been solved?

- Yes End

Note: After replacing the LED head, set the LED head drive time (See 3.2).

▼ No Replace the main control board or power supply/sensor board.

⑤ Cyclical defect

	Frequency	Remedy
Image drum	3.71" (94.2mm)	Replace or clean the image drum cartridge.
Developing roller	1.86" (47.12mm)	Replace the image drum cartridge.
Toner supply roller	2.96" (75.27mm)	Replace the image drum cartridge.
Charging roller	1.21" (30.63mm)	Replace the image drum cartridge.
Cleaning roller	0.93" (23.56mm)	Replace the image drum cartridge.
Transfer roller	1.95" (49.6mm)	Replace the transfer roller.
Heat roller	2.44" (62.0mm)	Replace the fusing unit assy.
Back-up roller	2.73" (69.4mm)	Replace the back-up roller.


Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (See Printer Handbook).

⑥ Prints voids


- Is the contact plate of the transfer roller in proper contact with the power supply/sensor board (see Figure 5-5)?
 - No Adjust the contact plate so that it touches the power supply/sensor board and the shaft of the transfer roller properly.
- ▼ Yes Replace the transfer roller.
- ▼ Has the problem been solved?
 - Yes End
- ▼ No Is the tension between the back-up roller (7.52kg) and the surface of back-up roller normal?
 - No Replace the back-up roller or bias spring.
- ▼ Yes Are the contacts of the toner supply roller, developing roller, image drum and charging roller in proper contact with the contact assy (see Figure 5-4 (A), (B), (C), (D), (E))?
 - No Adjust the contacts so that they touch the contact assy properly.
- ▼ Yes Replace the image drum cartridge.
- ▼ Has the problem been solved?
 - Yes End

Note: After replacing the image drum cartridge, reset the drum counter by clicking the "Reset" button in the Status Monitor. (See Printer Handbook).
- ▼ No Is the LED head being installed properly (check HEAD1 connectors on the main control board and PC Connector on the LED head)?
 - No Install the LED head properly.
- ▼ Yes Replace the LED head or the head cable.
- ▼ Has the problem been solved?
 - Yes End

Note: After replacing the LED head, set the LED head drive time (See 3.2).
- ▼ No Replace the main control board or power supply/sensor board.



⑧ White vertical belts or streaks






Figure 5-4





Figure 5-5


6. WIRING DIAGRAM

6.1 Interconnect Signal Diagram




6.2 PCB Layout and Connector Signal List

(1) Main Control Board (GRG-PCB)



(2) Power Supply/Sensor Board



- FAN Connector Pin Assignment
(To fan motor)

Opening		PIN NO.	I/O*	Signal	Description
	1	1	O	FANPOW	Power supply for fan driving
	2	2	C	OV	Ground
	3	3	I	FANALM-N	Fan alarm

- DM Connector Pin Assignment
(To main/drum motor)

	PIN NO.	I/O*	Signal	Description
1	1	O	DMPH1-P	Coil 1-P
2	2	O	DMPH1-N	Coil 1-N
3	3	O	DMPH2-P	Coil 2-P
4	4	O	DMPH2-N	Coil 2-N

Excitation sequence

PIN NO.	Line Color	Step No.			
		1	2	3	4
2	Yellow	+	-	-	+
4	Black	+	+	-	-
1	Orange	-	+	+	-
3	Brown	-	-	+	+

Rotary direction

Clockwise viewed from the output axis.

* I: In
O: Out
C: Common

- RM Connector Pin Assignment
(To registration motor)

	PIN NO.	I/O*	Signal	Description
1	1	O	RMPH1-P	Coil 1-P
2	2	O	RMPH1-N	Coil 1-N
3	3	O	RMPH2-P	Coil 2-P
4	4	O	RMPH2-N	Coil 2-N

* I: In
O: Out

Excitation sequence

PIN NO.	Line Color	Step No.			
		1	2	3	4
2	Yellow	+	-	-	+
4	Black	+	+	-	-
1	Orange	-	+	+	-
3	Brown	-	-	+	+

Rotary direction

Clockwise viewed from the output axis.

- HEAD1 Connector Pin Assignment
(To LED head)

	PIN NO.	I/O*	Signal	Description
1	1	C	0VLOGIC	Ground for Logic
2	2	O	HDCLK-P	Clock
3	3	C	0VLOGIC	Ground for Logic
4	4	O	HDD2-P	Data 2
5	5	O	HDD3-P	Data 3
6	6	C	0VLED	Ground for LED
7	7	O	HDD0-P	Data 0
8	8	O	HDD1-P	Data 1
9	9	C	+3.3V	+3.3V power supply for LED driving
10	10	O	HDDL-D-P	Load
11	11	O	HDSTB1-N	Strobe 1
12	12	C	HDSTB2-N	Strobe 2
13	13	O	HDSTB3-N	Strobe 3
14	14	C	HDSTB4-N	Strobe 4

* O: Out
C: Common

- HEAD2 Connector Pin Assignment
(To LED head)

	PIN NO.	I/O*	Signal	Description
1	1	O	+3.3V	+3.3V power supply for LED driving
2	2	O		
3	3	O		
4	4	O		
5	5	O		
6	6	O		
7	7	C	0VLED	Ground for LED
8	8	C		
9	9	C		
10	10	C		
11	11	C		
12	12	C	FG	FG

* O: Out
C: Common

- PANEL Connector Pin Assignment
(To operator panel)

	PIN NO.	I/O*	Signal	Description
1	1	C	+5V	+5V power supply
2	2	O	READY	Signal for READY
3	3	O	PAPER	Signal for PAPER
4	4	O	ALARM	Signal for ALARM
5	5	I	SW-N	Signal for Switch
6	6	C	0VL	Ground

* I: In
O: Out
C: Common

- ENVELOPE Connector Pin Assignment
(To option feeder I/F)

	PIN NO.	I/O*	Signal	Description
5	1	O	PAPERIN-N	Paper sense 1
2	2	O	SCLK-N	Clock
1	3	O	DATA-N	Data
3	4	I	PAPERIN-N	OPT send data ready
	5	C	OVP	Analog ground
	6	O	30V	+30V power supply
	7	C	0V	Logic ground
	8	O	5V	+5V power supply

* I: In
O: Out
C: Common

- 2NDTRAY Connector Pin Assignment
(To option tray I/F)

	PIN NO.	I/O*	Signal	Description
1	1	O	PAPERIN-N	Paper sense 1
2	2	O	SCLK-N	Clock
3	3	O	DATA-N	Data
4	4	I	PAPERIN-N	OPT send data ready
5	5	C	OVP	Analog ground
6	6	O	30V	+30V power supply
7	7	C	0V	Logic ground
8	8	O	5V	+5V power supply

* I: In
O: Out
C: Common

• POWER Connector Pin Assignment
(To power supply/sensor board)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
2	O	TRSEL-P	TR control switch	1	I	SQCR-N	Sequence clear signal of serial I/F
4	I	THERMCMP-P	Heater temperature	3	I	SCLK-N	Clock signal of serial I/F
6	I	CVOPN-N	Cover open (+5V)	5	I	PSIN1-N	Paper sense
8	O	DOUT-P	Serial data output	7	I	WRSNS-N	Reading of paper edge
10	I	RXD2-P	Serial data input	9	C	OVL	Ground for logic
12	I	+5V	Logic circuit supply voltage	11	I	+5V	Logic circuit supply voltage
14	I	+3.3V	LED head supply voltage	13	I	+3.3V	LED head supply voltage
16	C	OVL	Logic ground	15	C	OVL	Logic ground
18	I	+30V	Motor and fan drive voltage and source voltage for high voltage supply	17	I	+30V	Motor and fan drive voltage and source voltage for high voltage supply
20	O	HEATON-N	Heater on	19	O	TRSEL2-N	TR control switch
22	I		NC	21	C	0VP	Power (motor) ground
24	I	+12V	High voltage supply	23	C	0VP	Power (motor) ground
26	O	TRSEL3-N	TR control switch	25	C	0VP	Power (motor) ground

* O : Out
I : In
C : Common

• CENT Connector Pin Assignment
(To Centro parallel I/F)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
1	I	STROBE-N	Strobe	19	C	SG	Ground
2	C	DATA1-P	Data bit 0	20	C	SG	Ground
3	C	DATA2-P	Data bit 1	21	C	SG	Ground
4	C	DATA3-P	Data bit 2	22	C	SG	Ground
5	C	DATA4-P	Data bit 3	23	C	SG	Ground
6	C	DATA5-P	Data bit 4	24	C	SG	Ground
7	C	DATA6-P	Data bit 5	25	C	SG	Ground
8	C	DATA7-P	Data bit 6	26	C	SG	Ground
9	C	DATA8-P	Data bit 7	27	C	SG	Ground
10	O	ACK-N	Acknowledge	28	C	SG	Ground
11	O	BUSY-P	Busy	29	C	SG	Ground
12	O	PE-P	paper end	30	C	SG	Ground
13	O	SEL-P	Select	31	I	IPRIME-N	Input prime
14	I	AUTOFEED-N	Auto feed	32	O	FAULT-N	Fault
15		NC	Not connected	33	C	SG	Ground
16	C	SG	Ground	34		NC	Not connected
17	C	FG		35	O	HILEVEL	Always kept high
18	O	P-LOGIC-H	+5V power supply	36	I	SELIN-N	Select in

* O : Out

I : In

C : Common

- USB Connector Pin Assignment
(To USB I/F)

2	1
3	4

PIN NO.	I/O*	Signal	Description
1	I	Vcc	+5V Power supply
2	I/O	D-	USB Data
3	I/O	D+	USB Data
4	C	0V	Ground







* I: In
O: Out
C: Common



• OPTION Connector Pin Assignment
(To option RAM / RS232C or Network)

Pin No.	I/O*	Signal	Description	Pin No.	I/O*	Signal	Description
01	O	A0	OR write enable	51	I/O	D16	Data bit 16
02	C	0V	Logic ground	52	I/O	D0	Data bit 0
03	O	A1	Address bit 1	53	I/O	D17	Data bit 17
04	O	A2	Address bit 2	54	I/O	D1	Data bit 1
05	O	RSDTR0-N	RS232C Data terminal ready	58	I/O	D18	Data bit 18
06	O	A3	Address bit 3	56	I/O	D2	Data bit 2
07	O	A4	Address bit 4	57	I/O	D19	Data bit 19
08	C	0V	Logic ground	58	I/O	D3	Data bit 3
09	O	A5	Address bit 5	59	I/O	D20	Data bit 20
10	O	A6	Address bit 6	60	I/O	D4	Data bit 4
11	C	+5V	Logic power supply	61	I/O	D21	Data bit 21
12	O	A7	Address bit 7	62	I/O	D5	Data bit 5
13	O	A8	Address bit 8	63	I/O	D22	Data bit 22
14	C	0V	Logic ground	64	I/O	D6	Data bit 6
15	O	A9	Address bit 9	65	I/O	D23	Data bit 23
16	O	A10	Address bit 10	66	I/O	D7	Data bit 7
17	C	+5V	Logic power supply	67	I/O	D24	Data bit 24
18	O	A11	Address bit 11	68	I/O	D8	Data bit 8
19	O	A12	Address bit 12	69	I/O	D25	Data bit 25
20	C	0V	logic ground	70	I/O	D9	Data bit 9
21	O	A13	Address bit 13	71	I/O	D26	Data bit 26
22	O	A14	Address bit 14	72	I/O	D10	Data bit 10
23	C	+5V	Logic power supply	73	I/O	D27	Data bit 27
24	O	A15	Address bit 15	74	I/O	D11	Data bit 11
25	O	A16	address bit 16	75	I/O	D28	Data bit 28
26	C	0V	Logic ground	76	I/O	D12	Data bit 12
27	O	A17	Address bit 17	77	I/O	D29	Data bit 29
28	O	A18	Address bit 18	78	I/O	D13	Data bit 13
29	C	+5V	Logic power supply	79	I/O	D30	Data bit 30
30	O	A19	Address bit 19	80	I/O	D14	Data bit 14
31	O	A20	Address bit 20	81	I/O	D31	Data bit 31
32	C	0V	Logic ground	82	I/O	D15	Data bit 15
33	O	A21	Address bit 21	83	O	DRAS2-N	DRAM select 2
34	O	A22	Address bit 22	84	O	DRAS3-N	DRAM select 3
35	O	A23	Address bit 23	85	O	DRAS4-N	DRAM select 2
36	O	0V	Logic ground	86	O	DRAS5-N	DRAM select 5
37	O	0V	Logic ground	87	O	DCAS3-N	DCAS3
38	C	0V	Logic ground	88	O	DCAS2-N	DCAS2
39	O	RSRTS0-N	RS232C request to send	89	O	DCAS1-N	DCAS1
40	O	CS1-N	ROM/SRAM select 1	90	O	DCAS0-N	DCAS0
41	O	CS2-N	ROM/SRAM select 2	91	O	RD-N	RD-N
42	O	CS3-N	ROM/SRAM select 3	92	O	WR-N	WR-N
43	I	SCRREQ-P	SCC send request	93	I	INT1-N	Interrupt request 1
44	C	0V	Logic ground	94	I	INT2-N	Interrupt request 2
45	I	SCSREQ-P	SCC receive request	95	O	EEPRMCS1-P	EEPROM select
46	O	IOS0-N	I/O select 0	96	O	EEPRMCLK-P	EEPROM clock
47	O	IOS1-N	I/O select 1	97	C	SSTXD-P	EEPROM data
48	O	RSTXD0-N	RS232C send data	98	I	DRDY-N	Data read
49	O	-8V	RS232C line voltage	99	C	+8V	RS232C line voltage
50	I	RSRXD0-P	RS232C receive data	100	O	RESET-N	Reset signal


* O : Out
I : In
C : Common


6.3 Resistance Check

Unit	Circuit Diagram	Illustration	Resistance
Registration motor			Between Pins 1 and 2: 7.9Ω Between Pins 3 and 4: 7.9Ω
Main/drum motor			Between Pins 1 and 2: 8.6Ω Between Pins 3 and 4: 8.6Ω
Fusing unit			Between Pins 1 and 2: 120V 2Ω 240V 7Ω Between Pins 3 and 4: 200KΩ (at room temperature)

Unit	Circuit Diagram	Illustration	Resistance
Fan			

7. PARTS LIST





For B4200

Table 7-1 Lower Base Unit (1/3)

#:New Parts

No.	Patrs No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
1	3PP4083-6020P001	Hopping Roller Shaft	1	3	6	12	
2	4PB4076-5447P001	Rubber-Hopping Roller	1	3	6	12	
3	4PP4083-6022P002	Bearing	2	6	12	24	
4	4PB4083-6024P001	One-way Clutch Gear	2	6	12	24	
5	42174301	Roller-Regist	1	3	6	12	#
6	4PP4083-6031P001	Bearing(Registration)	1	3	6	12	
7	42174201	Roller-Pressure	1	3	6	12	#
8	41279501	Holder-Regist L	1	3	6	12	
9	41279601	Holder-Regist R	1	3	6	12	
10	41279801	Gear-Pressure	1	3	6	12	
11	41279401	Bearing-Pressure	2	6	12	24	
12	41281201	Spring-Tension	2	6	12	24	
13	41280401	Plate-Contact PA	1	3	6	12	
14	41279301	Bearing-Regist L	1	3	6	12	
15	41279701	Gear-Regist	1	3	6	12	
16	42208501	Roller Assy.-Transfer	1	3	6	12	#
17	40438001	Bearing TR	1	3	6	12	
18	41301801	Roller-Back up	1	3	6	12	
19	41584101	Spring Bias	2	6	12	24	
20	41536201	Holder-BU	2	6	12	24	
21	41584201	Bearing-Ball	2	6	12	24	
22	42208601	Lever-Reset L Assy.	1	3	6	12	#
23	3PP4083-6054P001	Reset Lever R	1	3	6	12	
24	3PP4083-6058P001	Switch Arm	1	3	6	12	
25	4PP4083-6057P001	Reset Spring	1	3	6	12	
26	42126101	Idle Gear	1	3	6	12	#
27	4PP4083-6081P001	Idle Gear	1	3	6	12	
28	4PP4083-6083P001	Sensor Plate(Inlet)	3	9	18	36	
29	40771401	Lever-Eject Sensor Assembly	1	3	6	12	
30	41027701	Sensor Wire Assembly	1	3	6	12	
31	4PP4083-6086G001	Toner Sensor(Adhesion)	1	3	6	12	
32	4PB4083-6979P001	Diselectrification Bar Shaft	1	3	6	12	
33	3PB4083-6089P001	Diselectrification Film	1	3	6	12	
34-a	42209201	Heat Assy	1	10	20	40	120V #
34-b	42209202	Heat Assy	1	10	20	40	230V #
35	40772501	Roller Assy.-Eject	1	3	6	12	
36	42145701	Cover Assy.-Front	1	3	6	12	#

Table 7-1 Lower Base Unit (2/3)

#:New Parts

No.	Patrs No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
37	42200401	Cover Assy.-Stacker	1	3	6	12	#
38	42129101	Holder-Head	1	3	6	12	#
39	42146701	Film-FG	1	3	6	12	#
40	42146501	Spring-Head	2	6	12	24	#
41	42408201	Cable-Assy-Head	1	5	10	20	#
42	42146601	Contact-Head	1	3	6	12	#
43	42266801	LED Head Unit-51MXF	1	5	10	20	#
44	42208301	Frame Subassy.-Lower	1	3	6	12	#
45	4PB4083-6197P001	Damper Frame	1	3	6	12	
46	42122701	Bracket-Motor(Caulking)	1	3	6	12	#
47	42352501	Bracket-Sub-M	1	3	6	12	#
48	42196001	Motor-Pulse(Main)	1	3	6	12	#
49	42196101	Motor-Pulse(Regist)	1	3	6	12	#
50	42121701	Gear-M3	1	3	6	12	#
51	42121801	Gear-M2	1	3	6	12	#
52	42121901	Gear-R2	1	3	6	12	#
53	4PP4120-1210P001	Washer C	1	3	6	12	
54	4PP4083-7663P001	FG Plate OP	1	3	6	12	
55	42209101	Guide-Paper R(Adhesive)	1	3	6	12	#
56	42200501	Plate-Base Assy.	1	3	6	12	#
57	4YC4061-5115P001	Polyethylene Tape	2	6	12	24	L=90mm
58	40828301	Guide-Paper H	2	6	12	24	
59	4PB4013-3501P002	CS-RING(CS3-SUS)	2	6	12	24	
60	42209401	Cassette guide L Assy.	1	3	6	12	#
61	42209501	Cassette guide R Assy.	1	3	6	12	#
62	3PP4083-7660P001	Beam Plate	2	6	12	24	
63	4PP4083-7665P001	FG Plate(bm)	2	6	12	24	
64	4PP4083-7667P001	Sensor Plate(Paper Supply)	1	3	6	12	
65	3PP4083-6154P001	Cassette Sensor Plate	1	3	6	12	
66	42146301	Insulator	1	3	6	12	#
67	42263804	Board-GRG	1	5	10	20	#
68-a	41991601	Power Supply Unit	1	5	10	20	100V/120V #
68-b	41991701	Power Supply Unit	1	5	10	20	230V #
69	42284101	Board-HLB	1	5	10	20	#
70	2381026P0014	Sumi-Card(30P)	1	5	10	20	#
71	42101001	Cord Assy.(13p-5P,8p)	1	5	10	20	#
72	42283501	Fan Motor	1	3	6	12	#
73	42209601	Cassette Assy.-Paper	1	3	6	12	#

Table 7-1 Lower Base Unit (3/3)

#:New Parts

No.	Patrs No.	Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks
				per 500	per 1000	per 2000	
74	42146201	Plate-Guide	1	3	6	12	#
75	40997101	Cord Assy.-OP	1	5	10	20	
76	42146801	Face Up Stacker Assy.	1	3	6	12	#
77-a	42200201	Frame Assy.-OP Panel	1	3	6	12	B4200(ODA) #
77-b	42200202	Frame Assy.-OP Panel	1	3	6	12	B4200(OUK/AOS) #
78	42147201	Cover-Upper Assy.	1	3	6	12	#
79	42129601	Cover-IF	1	3	6	12	#
90	42406601	Holder-Tr_R	1	3	6	12	#
91	42406701	Spacer-Tr_L	1	3	6	12	#
92	PP4128-1131P001	Plate-Earth_A	1	3	6	12	
	Option						
81	42160909	Board GRL	1				
82	42160910	Board GRL-2	1				
83							
84	42264009	Board GRM	1				
85	42264010	Board GRM-2	1				
86							
87	42264205	Board GRJ	1				
	Consumable						
88-a	42102801	Image Drum Unit Type 9	1				ODA
88-b	42102802	Image Drum Unit Type 9	1				OEL
88-c	42102803	Image Drum Unit Type 9	1				AOS
89							
90-a	42103001	Toner Cartridge Type 9(2.5K)	1				ODA(2.5k)
90-b	42103002	Toner Cartridge Type 9(2.5K)	1				OEL(2.5k)
90-c	42103003	Toner Cartridge Type 9(2.5K)	1				AOS(2.5k)

APPENDIX A RS-232C SERIAL INTERFACE (option)

1) Connector

- Printer side : 25-pin receptacle
Type DB-25S (made by Canon) or equivalent
- Cable side : 25-pin plug
Type DB-25S (made by Canon)
Shell
Type DB-C8-J10-F2-1 (made by Nihon Kouku Denshi) or equivalent

Note: Plug shall be fixable with a lock screw.

2) Cable


- Cable length : 6 ft (1.8 m) max. (cable shall be shielded)

Note: Cable is not provided.

3) Interface signal

Pin No.	Signal name	Abbreviation	Signal direction	Functions
1	Frame Ground	FG		Frame Ground
2	Transmitted Data	TD	← PR	Transmitted Data
3	Received Data	RD	→ PR	Received Data
4	Request to Send	RTS	← PR	Stay space level
5	-			(Not connected)
6	-			(Not connected)
7	Signal Ground	SG		Signal Ground
9 ~ 17	-			(Not connected)
18	-			(Not connected)
19	-			(Not connected)
20	Data Terminal Ready	DTR	← PR	Data terminal ready
21 ~ 25	-			(Not connected)

- Connector pin arrangement



(View from the cable side)


When the Ready/Busy protocol is used for the buffer busy control method, the busy signal can be set to Pin-20 (DTR) in the menu.

4) Signal Level


- MARK polarity : -3V to -15V (LOGIC = 1)
- SPACE polarity : +3V to +15V (LOGIC = 0)

5) Interface Circuit

a) Receiving Circuit



b) Sending Circuit



Note: The signal levels described above is for the case where $3K\ \Omega \times 15pF$ is connected to the terminal.

6) Receive Margin

37% min. at all reception rates.

7) Communications Protocol

- READY/BUSY protocol
- X-ON/X-OFF protocol

APPENDIX B CENTRONICS PARALLEL INTERFACE

1) Connector

- Printer side : 36-pin receptacle
(single port) Type 57RE-40360-730B-D29A (made by Daiichi Denshi), CN-AX05841A36AT (made by Ougat) or equivalent
- Cable side : 36-pin plug
Type 57-30360 (made by Daiichi Denshi) or equivalent
Plug-552274-1 (AMP), 552073-1 (AMP) or equivalent

2) Cable


- Cable length : 6 ft (1.8 m) max.
(A Shielded cable composed of twisted pair wires is recommended for noise prevention.)

Note: Cable is not supplied with the printer, and is not available from Oki.

3) Table of Parallel I/F Signals

Pin No.	Signal name	Signal direction	Functions
1	DATA STROBE	→ PR	Parallel data sampling strobe
2	DATA BIT - 1	→ PR	PR Parallel input and output data
3	DATA BIT - 2		
4	DATA BIT - 3		
5	DATA BIT - 4		
6	DATA BIT - 5		
7	DATA BIT - 6		
8	DATA BIT - 7		
9	DATA BIT - 8		
10	ACKNOWLEDGE	← PR	Completion of data input or end of a function
11	BUSY	← PR	During print processing or alarm
12	PAPER END	← PR	End of paper
13	SELECT	← PR	Select state (ON-LINE)
14	AUTOFEED	→ PR	Request to change mode
15	-		(Not used)
16	0V		Signal ground
17	CHASSIS GROUND		Chassis ground
18	+5V	← PR	50 mA max.
19 ⋮ 30	0V		Signal ground
31	INPUT PRIME	→ PR	Initializing signal
32	FAULT	← PR	End of paper or during alarm
33	-		Signal ground
34	-		(Not used)
35	-		High level (3.3 kΩ)
36	SELECT IN	→ PR	Request to change mode

• Connector pin arrangement



4) Signal Level




- LOW : 0 V to +0.8 V
- HIGH : +2.4 V to 5.0 V

5) Specifications


Item	Description
Mode	Compatibility mode, Nibble mode, ECP mode
Data bit length	8 bits (in the compatibility mode)
Input prime	Valid/Invalid
Receive buffer	0.1M, 0.2M, 0.5M Bytes
Control	Handshaking control is performed in each mode. Data received from the host is stored in the receive buffer. Busy control is performed. Signal lead control is performed.

6) Timing Charts

a) Data receiving timing

b) On-line \rightarrow off-line switching timing by ON-LINE SWc) Off-line \rightarrow on-line switching timing by ON-LINE SW

d) INPUT PRIME timing (when set to the effective INPUT PRIME signal)



APPENDIX C Universal Serial Bus (USB)

Universal Serial Bus Specification Revision 2.0 full speed compliance.

1) Connector

- Printer Side : "B" Receptacle (Upstream Input to the USB Device)
- Cable Side : Series "B" Plug

2) Cable


- Cable Length : Max 5m (A cable must be met USB Spec Rev 1.1 for normal operation)

Note: Cable is not provided.

3) Table of USB I / F signals

Contact Number	Signal Name
1	Vbus
2	D -
3	D +
4	GND
Shell	Shield

4) Connector pin arrangement




5) Mode & Class of Device

- Full - speed Driver
- Self - powered Device

6) Data Signaling Rate

- Full - speed function - 12Mb/s

7) Interface circuit



8) Signal Level

• Input / Output Level

Parameter	Symbol	Min.	Max.	Units
Input Levels :				
High (driven)	V _{IH}	2.0		V
High (floating)	V _{IHZ}	2.7	3.6	V
Low	V _{IL}		0.8	V
Output Levels :				
Low	OL	0.0	0.3	V
High (driven)	OH	2.8	3.6	V
Output Signal Crossover Voltage	VC _{RS}	1.3	2.0	V


• Signaling Levels

Bus State	Signaling Levels	
	Required	Acceptable
Differential "1"	(D+) - (D-) > 200mV and D+ > V _{IH} (min)	(D+) - (D-) > 200mV
Differential "0"	(D-) - (D+) > 200mV and D- > V _{IH} (min)	(D-) - (D+) > 200mV
Single-ended 0 (SE0)	D+ and D- < V _{IL} (max)	D+ and D- < V _{IH} (min)
Data J state:		
Low-speed	Differential "0"	
Full-speed	Differential "1"	
Data K state:		
Low-speed	Differential "1"	
Full-speed	Differential "0"	
Idle state:		
Low-speed	D- > V _{IHZ} (min) and D+ < V _{IL} (max)	D- > V _{IHZ} (min) and D+ < V _{IH} (min)
Full-speed	D+ > V _{IHZ} (min) and D- < V _{IL} (max)	D+ > V _{IHZ} (min) and D- < V _{IH} (min)
Resume state	Data K state	
Start-of-Packet (SOP)	Data lines switch from Idle to K state	
End-of-Packet (EOP)	SE0 for ≥ 1 bit time ¹ followed by a J state for 1 bit time	SE0 for ≥ 1 bit time ¹ followed by a J state
Disconnect (at downstream port)	SE0 for ≥ 2.5μs	
Connect (at downstream port)	Idle for ≥ 2ms	Idle for ≥ 2.5μs
Reset	D+ and D- < V _{IL} (max) for ≥ 10ms	D+ and D- < V _{IL} (max) for ≥ 2.5μs


Note: The width of EOP is defined in bit times relative to the device type receiving the EOP. The bit time is approximate.

9) Timing Chart


a) Packet Voltage Levels




b) Disconnect Detection




c) Full-speed Device Connect Detection




d) Differential Data Jitter



e) Differential-to-EOP Transition Skew and EOP Width



f) Receiver Jitter Tolerance



APPENDIX D MULTI PURPOSE FEEDER MAINTENANCE

1. OUTLINE

1.1 Functions

This Multi-Purpose Feeder is installed on the front section of the printer, and it supplies paper automatically through the operation of pulse motor, which is driven by signals sent from the printer. The main functions are the followings:

- Paper that can be used:

[Paper Types]

- Standard paper: Xerox 4200 (20-lb)
- Special paper: OHP sheets (for PPC), label sheets (PPC sheets)
* Not guaranteed for OHP sheets with attachments on the edge or reverse side.
- Cut sheet size: Letter, Executive, A4, A5, B5, A6, COM9, COM10, Monarch, DL, C5
- Special size: Width: 87 to 216mm
Length: 148 to 297mm

[Weight and Thickness]

- 16-lb to 32-lb (60~128 g/m²)
- For labels and OHP Sheets: Label sheets: 0.1 to 0.15mm
OHP sheets: 0.08 to 0.11mm

* When using sheets which exceed 24-lb, make sure that the paper exits through the face-up route.

1.2 External View and Component Names




Figure 1-1

2. MECHANISM DESCRIPTION


2.1 General Mechanism

The Multi-Purpose Feeder feeds the envelopes and paper into the printer by receiving the signal from the printer, which drives the pulse motor inside the Multi-Purpose Feeder, and this motion is transmitted to rotate roller-A and B. The envelope or paper is delivered from the separator into the printer.

Once delivered into the printer, the envelope or paper is then controlled and fed through by pulse motor (registration) of the printer.

2.2 Hopper Mechanism

The hopper automatically feeds the printer with the envelope or paper being set, one sheet at a time. After the envelope or paper is set in the Multi-Purpose Feeder, the pulse motor moves the envelope or paper and a single envelope or paper caught by the separator is fed into the printer.



3. PARTS REPLACEMENT

This section covers the procedures for the disassembly, reassembly and installations in the field. This section describes the disassembly procedures, and for reassembly procedures, basically proceed with the disassembly procedures in the reverse order.








3.1 Precautions Concerning Parts Replacement

- (1) Parts replacements must be carried out, by first turning the printer power switch off "O" and removing the Multi-Purpose Feeder from the printer.
- (2) Do not disassemble the Multi-Purpose Feeder if it is operating normally.
- (3) Establish the extent of disassembly suitable for the purpose of the procedure, and do not disassemble any more than necessary.
- (4) Only specified service tools may be used.
- (5) Disassembly must be carried out according to the prescribed procedures. Parts may be damaged if such procedures are not followed.
- (6) Small parts such as screws and collars can easily be lost, therefore these parts should be temporarily fixed in the original location.
- (7) When handling printed circuit boards, do not use any glove which may generate static electricity.
- (8) Do not place the printed circuit boards directly on the equipment or floor.

[Service Tools]

Table 3-1 shows the tools required for the replacement of printed circuit boards, assemblies and units in the field.

Table 3-1 Service Tools

No.	Service Tools	Q'ty	Application	Remarks
1	 No. 1-100 Philips screwdriver	1	2 ~ 2.5 mm screws	
2	 No. 2-100 Philips screwdriver	1	3 ~ 5 mm screws	
3	 No. 3-100 screwdriver	1		
4	 No. 5-200 screwdriver	1		
5	 Digital multimeter	1		
6	 Pliers	1		
7	 Handy cleaner	1		

3.2 Parts Layout

This section describes the layout of the main components.





Figure 3-1

3.3 Parts Replacement Methods


This section describes the parts replacement methods for the components listed in the disassembly order diagram below.



3.3.1 Link


- (1) Open paper feed cover ①, and disengage the paper feed cover ① and link ③, while lifting the paper hold ②.
- (2) Remove the paper hold ② off the arm ④.
- (3) Disengage the link ③ from the arm ④, and remove it.

* Be careful not to deform the link and arm.



3.3.2 Separator



- (1) Turn the power switch off "O" and remove the connector cable.
- (2) Disengage the link and paper feeder cover (see 3.3.1).
- (3) Remove 2 screws ①, disengage the locks at 2 locations on the upper frame ② with a screwdriver, and remove the upper frame ②.
- (4) Remove 2 screws ③, and take out the separator assembly ④.
- (5) Disengage the separator ⑦ from the separator bracket ⑥ while lifting the paper hold ⑤, and take out the separator (be careful not to lose the spring ⑧ when you are doing this).



3.3.3 OLEV-11-PCB


- (1) Remove the upper frame [see 3.3.2 steps (1) through (3)].
- (2) Remove the connector ①.
- (3) Remove 2 screws ②, and remove the OLEV-11 PCB ③.

When reinstalling the printed circuit board, be careful to make sure that the sensor plate is being set correctly.




3.3.4 Pulse Motor

- (1) Remove the upper frame [see 3.3.2 steps (1) through (3)].
- (2) Remove the OLEV-11-PCB (see 3.3.3).
- (3) Remove 2 screws ①, and remove the pulse motor ②.



3.3.5 Planet Gear


- (1) Remove the upper frame [see 3.3.2 steps (1) through (3)].
- (2) Remove the OLEV-11-PCB (see 3.3.3).
- (3) Remove 2 screws ①, and remove the motor bracket assembly ② and planet gear ③.



3.3.6 Roller-A and B

While only the removal procedure for roller-A is described here, the removal procedure for roller-B is basically same. When removing roller-B, however, be careful not to deform the sensor plate.

- (1) Remove the upper frame [see 3.3.2 steps (1) through (3)].
- (2) Remove the separator assembly (see 3.3.2).
- (3) Remove the OLEV-11-PCB (see 3.3.3).
- (4) Remove the motor bracket (see 3.3.5).
- (5) Remove the gear ①.
- (6) Shift the roller-A ② to the right, lift it on its left side and slide it out (the bearing ③ also comes off while you are doing this, so be careful not to lose it).



4. TROUBLESHOOTING


4.1 Precautions Prior to the Troubleshooting

- (1) Go through the basic checking items provided in the Printer Handbook.
- (2) Obtain detailed information concerning the problem from the user.
- (3) Go through checking in the conditions similar to that in which the problem occurred.

4.2 Preparations for the Troubleshooting

- (1) Display on the operator panel
The status of the problem is displayed on the LED on the operator panel.

[For ODA]




[For OEL/INT]



4.3 Troubleshooting Method




When a problem occurs, go through the troubleshooting according to the following procedure.



4.3.1 LCD Status Message List


The listing of the statuses and problems displayed in the form of messages on the LCD is provided in Table 4-1.

Table 4-1

Classification	LED Status Message	Description	Recovery method
Jam error	 Blinking OFF OFF	Notifies of occurrence of jam while the paper is being fed from Multi-Purpose Feeder.	<ul style="list-style-type: none"> • Check the paper in the Multi-Purpose Feeder. • Carry out the recovery printing by opening and closing the cover, and turn the error display off. • When the problem occurs frequently, go through the Troubleshooting.
Paper size error	 Blinking OFF OFF	Notifies of incorrect size paper feeding from Multi-Purpose Feeder.	<ul style="list-style-type: none"> • Check the paper in the Multi-Purpose Feeder. • Also check to see if there was a feeding of multiple sheets. • Carry out the recovery printing by opening and closing the cover, and turn the error display off.
Tray paper out	 Blinking OFF OFF	Notifies of no paper state of the Multi-Purpose Feeder.	<ul style="list-style-type: none"> • Load the paper in Multi-Purpose Feeder.


- (JAM error)

Paper Inlet Jam




5. CONNECTION DIAGRAM

5.1 Interconnection Diagram



5.2 PCB Layout

OLEV-11-PCB



6. PARTS LIST




Figure 6-1 Multi-Purpose Feeder

Table 6-1 Multi-Purpose Feeder

No.	Description	OKI-J Part No.	ODA Part No.	Q'ty	Remark
1	Roller-A	3PB4083-5514P001		1	
2	Roller-B	3PB4083-5524P001		1	
3	Planet gear	4PP4083-5520P001		1	
4	Link	3PP4083-5540P001		1	
5	Separator	4PP4083-5544G001		1	
6	Pulse motor	4PB4083-6075P001		1	Same as printer unit.
7	OLEV-11-PCB	4YA4121-1014G011		1	
8	Connector cable	3YS4011-3141P003		1	ODA (exist the label)
		3YS4011-3141P001		1	OEL/INT(without the label)
9	Separator assy	3PA4083-5549G001		1	

APPENDIX E HIGH CAPACITY SECOND PAPER FEEDER

1. OUTLINE

1.1 Functions

The printer is mounted on top of this High Capacity Second Paper Feeder. The High Capacity Second Paper Feeder supplies paper automatically through the operation of pulse motor (hopping), which is driven by signals sent from the printer.

The main functions are the followings:

- Paper that can be used:

[Paper Type]

- Standard paper: Xerox 4200 (20-lb)
- Special paper: OHP sheets (for PPC), Label sheets (PPC sheets); use of envelopes or thick paper is not possible.
- Cut sheet size: A4, A5, B5, Letter, Executive, Legal13, Legal14
- Special size: Paper width: 148 to 216mm
Paper length: 210 to 355.6mm

[Weight]

- 16-lb to 24-lb (60 to 90 g/m²)
- Paper setting quantity: 500 sheets of paper weighing 64 g/m²

1.2 External View and Component Names




Figure 1-1 External View and Component Names

2. MECHANISM DESCRIPTION


2.1 General Mechanism

The High Capacity Second Paper Feeder feeds the paper into the printer by receiving the signal from the printer, which drives the pulse motor inside the High Capacity Second Paper Feeder, and this motion is transmitted to rotate the one-way clutch of the hopping frame assembly. The paper is delivered from the hopper into the printer through the turning of the hopping roller and feed roller.

Once delivered into the printer, the paper is then controlled and fed through by pulse motor (registration) of the printer.

2.2 Hopper Mechanism

The hopper automatically feeds the printer with the paper being set, single sheet at a time. When the paper is loaded in the paper cassette, it is then transported by the pulse motor, carrying forward only a single sheet caught by the brake shoe at a time.



3. PARTS REPLACEMENT

This section covers the procedures for the disassembly, reassembly and installations in the field. This section describes the disassembly procedures, and for reassembly procedures, basically proceed with the disassembly procedures in the reverse order.






3.1 Precautions Concerning Parts Replacement

- (1) Parts replacements must be carried out, by first turning the printer power switch off "O" and removing the printer from the High Capacity Second Paper Feeder.
- (2) Do not disassemble the High Capacity Paper Feeder if it is operating normally.
- (3) Establish the extent of disassembly suitable for the purpose of the procedure, and do not disassemble any more than necessary.
- (4) Only specified service tools may be used.
- (5) Disassembly must be carried out according to the prescribed procedures. Parts may be damaged if such procedures are not followed.
- (6) Small parts such as screws and collars can easily be lost, therefore these parts should be temporarily fixed in the original location.
- (7) When handling printed circuit boards, do not use any glove which may generate static electricity.
- (8) Do not place the printed circuit boards directly on the equipment or floor.

[Service Tools]

Table 3-1 shows the tools required for the replacement of printed circuit boards, assemblies and units in the field.

Table 3-1 Service Tools

No.	Service Tools	Q'ty	Application	Remarks
1	 No. 1-100 Philips screwdriver	1	2 ~ 2.5 mm screws	
2	 No. 2-100 Philips screwdriver	1	3 ~ 5 mm screws	
3	 No. 3-100 screwdriver	1		
4	 Digital multimeter	1		
5	 Pliers	1		

3.2 Parts Layout

This section describes the layout of the main components.





Figure 3-1


3.3 Parts Replacement Methods

This section describes the parts replacement methods for the components listed in the disassembly order diagram below.





3.3.1 Stepping Motor (Hopping)

- (1) Turn the printer power switch off, pull out the AC cord from the outlet. Remove the printer off High Capacity Second Paper Feeder.
- (2) Take the paper cassette assy ❶ out of High Capacity Second Paper Feeder.
- (3) Remove six screws ❷ and remove the upper plate ❸. Remove two screws ❹ and remove the hopping frame assy ❺.
- (4) Remove the front cover assy ❻ off the guide boss on the guide L (2nd) assy ❼ by bending the guide L (2nd) assy ❼ in the direction of arrow shown in the magnified view below.
- (5) Pull the sheet guide assy ❸ in the direction of arrow ㉞ and also push in the direction of arrow ㉟ to unlock the notch, and bring the sheet guide assy ❸ in the direction of arrow ㊱ to remove the sheet guide assy ❸.




- (6) Remove three screws ⑨ which are holding the guide R (2nd) assy ⑩ to the bottom plate ⑪. Remove the screw ⑫ which is keeping the rear cover ⑬ and guide R (2nd) assy ⑩. Remove the guide R (2nd) assy ⑩.
- (7) Remove the protect (M) ⑭, guide bracket ⑮, planet gears ⑯ and planet gear bracket ⑰.
- (8) Remove the E-ring ⑱ which is keeping the sheet link ⑲ on the guide R (2nd) assy ⑩, and pull out the hinge stand ⑳.
- (9) Remove three remaining screws ㉑ which are keeping the motor on the motor bracket ㉒, and remove the connector off the Stepping Motor ㉓.
- (10) Remove two screws ㉔ on the Stepping Motor ㉓.

Note : The guide bracket ⑮ must be attached as shown in the following illustration:



The upper plate ③ must be attached as shown in the following illustration.



3.3.2 TQSB-2 PCB


- (1) Remove the pulse motor (see 3.3.1).
- (2) Remove the connectors ②⑥, ②⑦ from the GRT PCB ②⑧.
- (3) Remove the screw ②⑨ and remove the GRT PCB ②⑧.

Note : Refer to Detail A in the previous page.

3.3.3 Hopping Roller Shaft Assy and One-way Clutch Gear

- (1) Follow up to step (3) of 3.3.1 and remove the hopping frame assy.
- (2) Remove the screw ① and remove the earth plate ②. Remove the sensor lever (T) ③ and remove the transion spring ④ and remove the ground plate ⑤. Remove the gear ⑥ and remove the metal bush ⑦ and hopping roller shaft assy ⑧.
- (3) Remove the E-ring ⑨ and remove the one-way clutch gear ⑩ on the right side of the feed roller ⑪.

Note : The metal bush ⑫ also comes off. Be careful not to lose it.



The tension lever and the sensor lever need concurrent replacing.

4. TROUBLESHOOTING


4.1 Precautions Prior to the Troubleshooting

- (1) Go through the basic checking items provided in the Printer Handbook.
- (2) Obtain detailed information concerning the problem from the user.
- (3) Go through checking in the conditions similar to that in which the problem occurred.

4.2 Preparations for the Troubleshooting

- (1) Display on the Operator panel
The status of the problem is displayed on the LED on the Operator panel.

[For ODA]




[For OEL/INT]



4.3 Troubleshooting Method






When a problem occurs, go through the troubleshooting according to the following procedure.



4.3.1 LED Status Message List


The listing of the statuses and problems displayed in the form of messages on the status monitor is provided in Table 4-1.

Table 4-1

Classification	LED Status Message	Description	Recovery method
Jam error (feeding)	 Blinking OFF OFF	Notifies of occurrence of jam while the paper is being fed from High Capacity Second Paper Feeder.	<ul style="list-style-type: none"> Check the paper in the High Capacity Second Paper Feeder. Carry out the recovery printing by opening and closing the cover, and turn the error display off. <ul style="list-style-type: none"> When the problem occurs frequently, go through the Troubleshooting.
Jam error (ejection)	 Blinking OFF OFF	Notifies of occurrence of jam while the paper is being ejected from the printer.	<ul style="list-style-type: none"> Check the paper in the printer. Carry out the recovery printing by opening and closing the cover, and turn the error display off.
Paper size error	 Blinking OFF OFF	Notifies of incorrect size paper feeding from High Capacity Second Paper Feeder.	<ul style="list-style-type: none"> Check the paper in the High Capacity Second Paper Feeder. Also check to see if there was a feeding of multiple sheets. Carry out the recovery printing by opening and closing the cover, and turn the error display off.
Tray paper out	 Blinking OFF OFF	Notifies of no paper state of the High Capacity Second Paper feeder.	<ul style="list-style-type: none"> Load the paper in High Capacity Second Paper Feeder.
Paper size request	 Blinking OFF OFF	Notifies of correct paper size for the High capacity Second Paper Feeder.	<ul style="list-style-type: none"> Load the requested size paper in the High Capacity Second Paper Feeder.


- (JAM error)

Paper Inlet Jam




5. CONNECTION DIAGRAM

5.1 Interconnection Diagram



5.2 PCB Layout

GRT PCB



6. PARTS LIST





Figure 6-1 High Capacity Second Paper Feeder


Table 6-1 High Capacity Paper Feeder

No.	Description	OKI-J Part No.	Q'ty	Remark
1	Hopping roller shaft assy	3PA4122-1367G001	1	
2	One-way clutch gear	4PB4122-1382P001	1	
3	Stepping motor	3PB4122-1399P001	1	
4	Board-GRT	42372702	1	
5	Cassette assy (2nd tray)	1PA4122-1362G004	1	
6	DIN8P-DIN8P Connection Cord	42372601	1	

2nd Tray ASSEMBLY



SECTION1 CABINET & CASSETTE ASSEMBLY



SECTION2 MECHANICAL ASSEMBLY




Table 6-2 2nd Tray Parts List


No.	Description	OKI Parts No.	Q'ty/U	500	1000
1	Plate, upper	1PP4122-1401P001	1	3	5
2	Sheet guide assembly	3PA4122-1370G001	1	3	5
3	Front cover assembly	1PA4122-1369G001*	1	3	5
4	Inner guide assembly	3PA4122-1371G001	1	3	5
5	Cassette assembly (2nd tray)	1PA4122-1362G004**	1	3	6
6	Separation frame assembly	4PA4120-1009G001	1	6	12
7	Cover, rear	1PP4122-1323P001	1	3	5
8	Stick finger	4PB4122-1441P001	1	3	5
9	Hopping flame assembly	1PA4122-1366G001	1	3	6
10	Bush, metal (ADF)	4PP3522-3568P001	1	3	5
11	Gear (z70)	4PP4122-1207P001	1	3	5
12	Lever, sensor (p)	3PP4122-1331P001	1	3	5
13	Feed roller assembly	3PA4122-1393G001	1	3	5
14	Cable & connector	3YS4111-3528P001	1	3	5
15	Stepping motor	3PB4122-1399P001	1	3	6
16	Bracket	4PP4122-1384G001	1	3	5
17	Gear (z24)	4PP4122-1383P001	2	3	5
18	Gear (z87/z60)	4PP4122-1226P001	1	3	5
19	Plate, bottom	2PP4122-1389P001	1	3	5
20	2nd cassette guide (L) assy	1PA4122-1365G001	1	3	6
21	Hopping roller assembly	3PA4122-1367G001	1	3	6
22	2nd cassette guide (R) assy	42337801	1	3	6
23	One-way clutch gear	4PB4122-1382P001	1	6	12
24	Board-GRT	42372702	1	3	6
25	Spring, Tension	41804801	1	3	6
26	Lever, sensor (T)	PP4122-1416P001	1	3	6
27	DIN8P-DIN8P Connection Cord	42372601	1	3	6

* For the rev. no. of the Parts List for the Front cover assembly should be applied No.6.

The No.6 includes a change of Release spring [P195, iv]

** For the rev. no. of the Parts List for the Cassette assembly (2nd tray) should be applied No.10.

The No.10 includes a change of cassette and Tale Guide.



Note : Cassette and Tale Guide need concurrent replacing.