SAMSUNG

DIGITAL LASER MFP


SCX-4200 Series

SCX-4200/XAX

Basic Model : SCX-4200

SERVICE *Manual*

DIGITAL LASER MFP



SCX-4200 Series

The keynote of Product

[Key Features]

- 18ppm Print/Copy Speed
- 600dpi Print/Copy Resolution
- 600 x 2400dpi Scan Resolution
- Samsung Print Language
- 8MB System Momory
- 250sh Paper Input/50sh Paper Output
- Under 42sec Warm-up Time
- 16 x 2 Line LCD Display
- USB 2.0
- 3K Toner Yield: initial(1K), sales(3K)
- Special Copy: ID Copy, Clone, 2-up, Poster, Autofit



ELECTRONICS

* This service manual is a property of Samsung Electronics Co., Ltd. Any unauthorized use of Manual can be punished under applicable international and/or domestic law.

* This service manual is also provided on the web, the ITSELF system Samsung Electronics Co., Ltd.

http://itself.sec.samsung.co.kr

ⓒSamsung Electronics Co.,Ltd. November. 2005
Printed in Korea.
VERSION NO. : 1.00 **CODE** : JC-0155C

Contents

1. Precautions

1.1 Safety Warning 1-1
1.2 Caution for safety 1-2
1.3 ESD Precautions 1-5
1.4 Super Capacitor or Lithium Battery Precautions 1-5

2. Product Specification

2.1 Product Overview 2-1
2.2 Specifications 2-2

3. System Overview

3.1 System Outline 3-1
3.2 H/W Structure abd Descriptions 3-9
3.3 S/W Structure and Descriptions 3-19

4. Alignment and Adjustments

4.1 Engine Test Mode 4-1
4.2 Paper Path 4-2
4.3 Clearing Paper Jams 4-3
4.4 Printing the System Data List 4-6
4.5 Clearing the Memory 4-6
4.6 Clearing the Drum 4-6
4.7 Consumables and Replacement Parts 4-7
4.8 The LCD Status Display by Each Error 4-7
4.9 Periodic Defective Image 4-8
4.10 Error Message 4-9

Continued

5. Disassembly and Reassembly

5.1 General Precautions on Disassembly 5-1
5.2 Front Cover 5-2
5.3 Rear Cover 5-3
5.4 DC Fan 5-4
5.5 Right Side Cover 5-5
5.6 Left Side Cover 5-6
5.7 Scanner Unit 5-7
5.8 OPE Unit 5-10
5.9 Middle Cover Unit 5-11
5.10 Fuser 5-12
5.11 Exit Roller 5-14
5.12 LSU 5-15
5.13 Fan 5-16
5.14 Drive Ass'y 5-16
5.15 Engine Shield Ass'y 5-17
5.16 Main PBA 5-17
5.17 SMPS 5-18
5.18 CRUM PCB 5-19
5.19 Transfer Roller 5-20
5.20 Feed Roller 5-21
5.21 Pick Up Roller & Solenoid 5-23

6. Troubleshooting

6.1 Procedure of Checking the Symptoms 6-1
6.2 Solution of Image Problem 6-5
6.3 Paper Feeding Problems and Troubleshooting 6-10
6.4 Symptoms of Bad Operation and Troubleshooting 6-13
6.5 Treatment of Error Message 6-17

Continued

7. Block diagram

7.1 System Block Diagram 7-1

8. Exploded Views & Parts List

8.1 Exploded Views and Parts List 8-1

9. Connection Diagram

9.1 SCX-4200 Connection Diagram 9-1

10. Schematic Diagram

10.1 Main Board 10-1
10.2 OPE Circuit Diagram 10-8
10.3 SMPS-110V 10-9
10.3 SMPS-220V 10-13

11. Reference Information

11.1 Tools for Troubleshooting 12-1
11.2 Acronyms and Abbreviations 11-2
11.3 Select a location for the printer 11-4
11.4 A4 ISO 19752 Standard Pattern 11-5